

# 8063 Aqua-Magic System

## UNLOCKING THE PUMP (after prolonged periods of rest)

- 1 Make sure that the batteries are charged and activate Aqua-Magic by turning the “FREQUENCY” dial to any program (to activate suction).
- 2 Cut a length of 2 inches of the feeding tube supplied and insert it on the “IN” water inlet. This is to help with the next step.
- 3 Insert a syringe without a needle filled with water into the tube and squirt the water inside. If necessary, repeat multiple times (you should see water coming out of the “OUT” water outlet). The pump is now unlocked.
- 4 Turn the timer to OFF.

